


AirKF 700



Ref. No.	Parts No.	Description	Q'ty	Ref. No.	Parts No.	Description	Q'ty
1	670-22	Inlet Bushing	1	39	693-13B	Collar	1
2	230-68	Valve Screw	1	40	693-12B	Collar	1
3	P-10	O-Ring	1	41	6905LLU	Ball Bearing	1
4	230-4	Valve Spring	1	42	693-4	Coupling	1
5	230-6	Valve Stem	1	43	693-53	Valve Spring	1
6	P-6	O-Ring	1	44	693-56	Valve	1
7	693L-4	Valve Housing incl. Bush (230-7)	1	45	693-52	Valve Pin	1
8	40-25	Roll Pin(4φ-25mm)	1	46	693-24B	Cutter Holder	1
9	1110RAL-2	Safety Lever	1	47	693-15	Clamp Screw	3
10	693L-2	Lock Ring	1	48	693-100C	Carbide Tip - 10pcs. in 1 box -	3
11	693L-1	Valve Joint	1	49	693-6	Lock Nut	1
12	991-7	O-Ring	1	50	693-46	Outer Case	1
13	693L-3	Handle Cover	1	51	HSW-50	Washer	4
14	693L-5	Toggle Lock	1	52	Z-M50--150	Cap Screw	4
15	693-20BDS	Motor Housing incl. Heli-coil (M5-2D)	1	53	693-47	Slide Ring	1
16	693-21	Handle Cover	1	54	P-5	O-Ring	2
17	620-28	O-Ring	2	55	AZM50--100	Screw	2
18	693-23A	Handle	1	56	693-5EC8	Guide Roller for thickness ≥ 13 mm	1
19	693-55	Exhaust Ring	1	57	693-19	Screw	1
20	P-26	O-Ring	2	58	693-14B	Base Plate	1
21	693-60	Muffler	1	59	LVM50--120	Cap Screw	4
22	693-59	Exhaust Screen	1	60	693-19A	Stopbolt for cooling air	1
23	693-54	Exhaust Bushing	1	61	WRA-3	3mm Allen Wrench	1
24	6200ZZ	Ball Bearing	1	62	WRA-4LB	Allen Wrench T Type	1
25	693-2A	Rear Plate	1	63	693-99BDS	Adjustment tool	1
26	30-8	Roll Pin(3φ8mm)	3				
27	693-30	Rotor	1				
28	913-18A	Rotor Blade	6				
29	691-4	Cylinder	1				
30	693-3B	Front Plate	1				
31	16002	Ball Bearing	1				
32	693-27	Motor Gasket	1				
33	693-8B	Spindle Housing	1				
34	SB-1/8	Steel Ball	1				
35	HSW-50	Washer	4				
36	Z-M50--180	Cap Screw	4				
37	693-35	Lock Nut	1				
38	6905ZZ	Ball Bearing	2				