





PIPE TOOLS & VISES
SINCE 1896

Quick Release™ Boru Kesiciler


Kullanım Talimatları




1. Unscrew knob one turn. Then, press zip nut to open the cutter.




2. Line up the cutter wheel with the cut-off mark. Push the bar assembly until the wheel touches the pipe or tubing.



3. Hand tighten knob 1/4 turn to 1/2 turn after wheel touches pipe or tubing.



4. Once tight, turn cutter around pipe or tubing one revolution in direction shown to ensure tracking.



5. Depending on pipe or tubing material, tighten knob 1/4 to 3/4 turn in direction shown. Repeat tightening each revolution until cut is complete.

NOTLAR:

Reed Quick Release™ Boru Kesiciler, takılı kesici bıçağa göre çeşitli boru tiplerini keser. Tüm ayrıntılar için Reed Kesici Bıçak tablolarına bakın.
Borunun ya da tesisatın içindeki çapağı almak için üçgen kazıyıcı kullanın.
Daha az çapak için ilerlemeyi daha kademeli uygulayın.
Kesici bıçağın ömrünü uzatmak için kesiciye yandan basınç uygulamayın.
Ayrıca kesici bıçağı boruya çok hızlı ilerletmeyin.

Kesici Bıçak Seçim Tablosu**

**Bakır Alüminyum, Paslanmaz Kalın Piring, Çelik Çelik
PE, PVC Cidar Kesici Boru Boru PP, ABS Plastikler**

TC1Q O OSS OP2 1-2PVC * TC1.6Q O OSS OP2 1-2PVC *
TC2Q O OSS OP2 1-2PVC * TC3Q 30-40 30-40SS 30-40P
3-6PVC 6QP TC4Q 30-40 30-40SS 30-40P 3-6PVC 6QP
TC5Q 30-40 30-40SS 30-40P 3-6PVC 6QP TC6Q 30-40
30-40SS 30-40P 3-6PVC 680PVC TC8Q 30-40 30-40SS
80P 680PVC 680PVC *REED Mandallı Makas kullanın
**Tüm ayrıntılar için REED Kesici Bıçak Tablosunun
tamamına bakın.